

## Interactive Mobile Development

## Worksheet 4 - BroadcastReceiver - Battery

You will be creating an application with 1 activity which show a Toast once the device connects to a Wi-Fi Network

## N.B. make use of the provided Table

- 1. Create a new Application called WifiBroadcastExample
- 2. Create a Main Activity (empty)
- 3. Create a new Java Class which extends BroadcastReceiver
- 4. Override the onReceive() method with the code below:

```
NetworkInfo info =
intent.getParcelableExtra(WifiManager.EXTRA_NETWORK_INFO);
if(info != null && info.isConnected()) {
    // Do your work.

// e.g. To check the Network Name or other info:
WifiManager wifiManager = (WifiManager)
    ontext.getSystemService(Context.WIFI_SERVICE);

WifiInfo wifiInfo = wifiManager.getConnectionInfo();
String ssid = wifiInfo.getSSID();
```

- 5. To the code above add a Toast displaying "Connected to" and the name of the SSID
- 6. Make reference to the presentation Broadcast and Register this receiver in the  ${\tt AndroidManifest.xml}$